

p0106 Map msensor
p0110 Intake Air Temperature Circuit Malfunction -fault present
p0120 Throttle position sensor circuit A malfunction
p0331 knock sensor 2 performance circuit range
p0120 throttle pedal position sensor switch a circuit mal
p0130 bank 1 sensor 1 O2sensor
p0150 bank 2 sensor 1 O2sensor
p0201 Injector circuit malfunction cylinder 1
p0202 Injector circuit malfunction cylinder 2
p0203 Injector circuit malfunction cylinder 3
p0204 Injector circuit malfunction cylinder 4
p0205 Injector circuit malfunction cylinder 5
p0206 Injector circuit malfunction cylinder 6
p0207 Injector circuit malfunction cylinder 7
p0208 Injector circuit malfunction cylinder 8
p0221 throttle/ pedal position sensor switch b circuit range
p0225 throttle pedal sensor switch c malfunction
p0231 fuel pump relay circuit low
p0234 turbo wastegate regulating solenoid valve.
p0243 Turbocharger Wastegate Solenoid A Malfunction
p0325 knock sensor 1 circuit malfunction
p0326 knock sensor 1 circuit performance range
p0330 knock sensor 2 circuit malfunction
p0331 knock sensor 2 circuit performance range
p0351 Ignition Coil A Primary/Secondary Circuit Malfunction
p0352 Ignition Coil B Primary/Secondary Circuit Malfunction
p0353 Ignition Coil C Primary/Secondary Circuit Malfunction
p0354 Ignition Coil D Primary/Secondary Circuit Malfunction
p0355 Ignition Coil E Primary/Secondary Circuit Malfunction
p0356 Ignition Coil F Primary/Secondary Circuit Malfunction
p0357 Ignition Coil G Primary/Secondary Circuit Malfunction
p0358 Ignition Coil H Primary/Secondary Circuit Malfunction
p0421 Warm Up Catalyst Efficiency Below Threshold (Bank 1)
p0500 Vehicle speed sensor malfunction
p0560 System voltage malfunction
p0650 Malfunction Indicator Lamp (MIL) Control circuit malfunction
p0700 transmission control system [auto box] MIL Request
p0701 Transmission Control System Range/Performance
p0702 Transmission Control System Electrical
p0703 Torque Converter/Brake Switch B Circuit Malfunction
p0704 Clutch Switch Input Circuit Malfunction
p0705 Transmission Range Sensor Circuit malfunction (PRNDL Input)
p0706 Transmission Range Sensor Circuit Range/Performance
p0707 Transmission Range Sensor Circuit Low Input
p0708 Transmission Range Sensor Circuit High Input
p0709 Transmission Range Sensor Circuit Intermittent
p0710 Transmission Fluid Temperature Sensor Circuit Malfunction
p0711 Transmission Fluid Temperature Sensor Circuit Range/Performance
p0712 Transmission Fluid Temperature Sensor Circuit Low Input
p0713 Transmission Fluid Temperature Sensor Circuit High Input
p0714 Transmission Fluid Temperature Sensor Circuit Intermittent
p1171 RH o2 sensor efficiency
p1172 lambda trim multiplicative
p1225 sensor position of butterfly 1
p1226 ACCEL. POTENTIOMETER INCONSIST
p1340 Alignment Between Camshaft and Crankshaft Signal (Bank 2)
p1540 Air Bypass Valve Circuit Malfunction
p1554 idle speed Control Throttle Position basic setting conditions not met
p1600 immobiliser
p1665 BRAKE PEDAL SWITCH INCONSIST

p2097 down stream fuel system 1/2 Rich

u1600 immobiliser??

Subtract 0x4000 for frame, 0x8000 for body and 0xC000 for communications

0x0101 = p0101 (I check engine/traction)

0x1200 = p1200

0x2020 = p2020

0x3434 = p3434

0x4108 = c0108 (Frame)

0x5999 = c1999

0x6598 = c2598

0x7040 = c3040

0x8224 = b0224 (Body)

0x9177 = b1177

0xA085 = b2085

0xB134 = b3134

0xC145 = u0145 (Communication)

0xD600 = u1600

0xE354 = u2354

0xF899 = u3899